

EPDM PRIMER TECHNICAL DATA SHEET

Fast, Easy Application
Quick Drying
Low Odour
Uniform Spray Pattern

DESCRIPTION:

Tuskbond EPDM Primer is a quick and easy solution designed to increase the adhesion potential of EPDM and other roofing membranes. Offering a fast and easy alternative to standard roll on primers, Tuskbond EPDM primer will increase the speed, quality and precision of a contractor's work. The primer is quick drying, ready to work on within minutes and each 22L canister will cover an area of 250m² (based off a 10g/m² dry coat weight) reducing both working time and overall cost.

TECHNICAL SPECIFICATION:

PROPERTY TUSKBOND EPDM PRIMER

Solvent Hydrocarbon, Acetone

Propellant Hydrocarbon

Solids Content (approx). 30%
Spray Pattern Web
Colour Black
Coverage (approx). 22L 250m²

14L 160m²

VOC 575g/l Available Sizes 22L, 14L

STORAGE & SHELF LIFE:

Protect from extremes of temperature in a controlled environment between 15 and 35°C, and away from direct sunlight. Do not stand on a cold concrete floor. Low temperatures can result in irreparable separation of the adhesive. If the product sprays like a jet, the canister is too cold. Warm to at least 10°C before using. DO NOT ALLOW THE PRODUCT TO FREEZE.

Stored under the correct conditions, in original, unopened containers, the product will have a shelf life of 12 months.





TUSKBOND Roofing Solutions

EPDM PRIMER TECHNICAL DATA SHEET

DIRECTIONS FOR USE:

- For best results the substrate and product should be used at temperatures between 15°C and 25°C.
- Connect a suitable spray tip, such as a Unijet 9501 to the end of the spray gun.
 Then connect the gun to the hose.
- Connect the hose and gun assembly to the canister and tighten the connections.
 Turn on the canister valve, if there are any leaks, tighten the connection at the source of the leak.
- The valve should remain open until the canister is used up. Use the locking nut on the gun after use. Turning off the valve will result in the product drying in the hose and gun causing blockages.

- Hold the spray gun 10-20cm and apply a uniform coat of primer, covering the entire surface.
- Allow time for the solvents to evaporate from the material, the primer should feel dry to the touch before being worked with.
 Dependant on ambient temperature this can take from 2 to 10 minutes.
- Once the primer is dried, it is ready to be worked on. Avoid contaminating the primed area with dust, as much as possible, as this will impair performance.
- To prolong the life of your equipment consider a Tuskbond GC22 canister gun and hose cleaning kit.

IMPORTANT: This product is not compatible with bituminous membranes or flexible PVC.

DISCLAIMER:

All the information in the Data Sheet is based on practical experience and is published in good faith. However, because we have no control over the manner or conditions in which our products are used, or over work undertaken or end product manufactured by the purchaser, we cannot accept liability for results. Responsibility for ascertaining the suitability of products for purpose rests with the purchaser. All conditions, representations, statements, warranties or guarantees whatsoever, whether express, implied or statutory, in respect of any goods manufactured, sold or supplied by us are hereby expressly excluded and we accept no liability in respect of any claim for damage or consequential loss caused to any property arising directly or indirectly out of the use of our products or goods.

